

ML7-R LATHE

	Page
Outline diagram	2
Serial number	3
Standard and dismantled equipment	4
Assembly instructions (motorising equipment)	5
Assembly instructions (machine fitted clutch)	8
Installation	9
Lubrication	15
Controls and adjustment	19
Headstock bearing adjustment	21
Clutch adjustment	24
Tumbler reverse, carriage, tailstock	25
Power carriage feed and screwcutting	28
Replacement of headstock vee belt	30
Chuck fitting	32
Instructions for ordering spares	33
Parts lists	34

Illustrations not binding in detail

MYFORD ML7-R 3 1/2" CENTRE LATHE

MYFORD ML7-R 3 1/2" CENTRE LATHE

MYFORD LATHES pass rigid inspection tests before shipment, and in order to maintain this built-in accuracy, they must be properly installed.

DO NOT OPERATE THE LATHE UNTIL
 * The machine has been correctly installed and levelled, and it has been thoroughly cleaned and lubricated.

* The instructions have been carefully read, and the controls and adjustments are understood.

MACHINE SERIAL No.

In the event of queries, or orders for spares, please state the number of the machine, as shown on the front of the bed at the left hand end of the facing for the rack, Fig. 2.

KR 146444

SERIAL NUMBER




Fig. 2

We are always pleased to answer any technical question in connection with our Products. When writing to the Works be sure to state the Serial letter and number of your Lathe.

DO NOT MOVE ANY PART OF THE MACHINE UNTIL ALL SURFACES HAVE BEEN THOROUGHLY CLEANED AND OILED




Fig. 1 Showing overall measurements for installation purposes

INSTALLATION

Unpacking

Great care is taken in the packing of ML7-R Lathes to ensure that the user will receive the Lathe in perfect condition, and it is important that unpacking should be carried out with the same care in order to avoid possible damage.

Shortages

Check the standard equipment supplied with the machine, as listed, and illustrated below.
All loose packing material (such as wood wool) should be set aside and thoroughly searched in the case of apparent shortages. If the missing items do not come to light, report the shortages immediately to the supplier from whom the machine was purchased.

Cleaning

Myford machines are shipped with all parts protected by a rust preventative; all traces of this should be removed with either petrol or paraffin.




Fig. 3 Lathe with standard equipment dismantled for packing

Dismantled Equipment

1. Lathe partially dismantled for packing.
2. Countershaft arm with motor base
3. Swing head assembly.
4. Swing head pivot shaft.
5. Cam shaft and lever assembly.
6. Countershaft.
7. Countershaft two step pulley.
8. Countershaft cone pulley.
9. Countershaft collar.
10. Motor base tie bars.
11. Headstock belt guard.
12. Motor drive belt guard and backplate.
13. Motor drive vee belt.
14. Tailstock.

Standard Equipment (loose)

15. Soft and hard centres.
16. Catchplate with peg.
17. 6 3/4" dia. faceplate.
18. 8 changeheels (to complete standard set of 14 - 6 are mounted on the machine). (Except ML7-RB quick-change lathes.)
19. Motor pulley.
20. 2 double ended spanners.
21. Cee spanner.
22. 5 hexagon keys.
23. Oil gun.
24. Descriptive matter, installation booklet, etc.

For checking only. Do not use these numbers for ordering.

ASSEMBLY OF MOTORISING EQUIPMENT (Standard Machine — no clutch)

References are to illustration Fig. 3 or to parts list drawing section 'motorising assembly'.

- a Remove motor base from countershaft arm (2) by releasing 2 B.A. cup point socket set screw (QR10) in motor base and 1/4" B.S.F. half dog point socket set screw (QR11) in countershaft arm and withdrawing pivot pin (QR9).
- b Remove outer 7/16" B.S.F. hexagon nut and washer (QR5 and QR4) from stud at back of bed. Screw second nut in as far as possible and check that second washer is in position on stud.
- c Mount the countershaft arm (2) on to the back of the headstock (Fig. 4) securing it with the four 1/4" B.S.F. hexagon head screws (QR2). At this stage these screws should be only lightly nipped.
- d Insert the camshaft (5) into the lower hole in the countershaft arm (lever to the left when looking on the rear of the machine) and locate with the 1/4" B.S.F. half dog point socket set screw (QR19) ensuring that the screw is not overtightened till it prevents free rotation.
- e Remove the hexagon head screw and washers from the swing head pivot shaft (4) and, looking on the rear of the machine, insert the tapped end of the shaft into the left hand bearing only of the countershaft arm. Place the swing head in position (long boss to the left) and push the pivot shaft through the left hand bearing. Place the tie bars (10) for the motor base on the shaft (Fig. 5). Push the shaft through the right hand bearings of the swing head and countershaft arm, at the same time, rotating the shaft so that the flat near the left hand end will line up with the 1/4" B.S.F. cup point socket set screw (QR30) in the left hand bearing of the countershaft arm. With the shaft projecting roughly 3/8" (3 mm) at the right hand end, tighten the grub screw sufficiently to allow the shaft to slide but at the same time preventing rotation. Slide the shaft and the swing head so that the 1/4" B.S.F. half dog point socket set screw (QR11) in the left hand bearing of the swing head can be tightened into the groove in the pivot shaft sufficiently for location but without preventing free rotation of the swing head.




Fig. 4

Fig. 5

Fig. 6

- f Remove both Woodruff keys from the countershaft (6). Looking on the front of the machine, insert the countershaft (full 7/8" diameter leading) through the left hand bearing in the swing head. Mount the four step countershaft pulley (8) on to it (small diameter to the left) and push the shaft through till it is supported in the right hand bearing. Holding a 'straight edge' firmly against the left hand side of the headstock vee cone pulley (Fig. 6) push the countershaft pulley to the left against it and check that its face is true to the straight edge. If it is not, pivot the countershaft arm about its securing screws till the faces of the two pulleys are in one plane. The axes of the countershaft and headstock spindle will now be parallel one to another and the countershaft arm may be secured by finally tightening the four 1/4" B.S.F. hexagon head screws (QR2). Next tighten the inner 7/16" B.S.F. hexagon nut (QR5) against the back of the countershaft arm. Tighten firmly but not sufficiently to cause distortion. Place the outer washer on to the stud, followed by the outer 7/16" B.S.F. hexagon nut and lock the latter tight. Remove the countershaft and countershaft vee cone pulley.



Fig. 7




Fig. 8

- g** Release and remove hexagon nut and washer (QR16 and QR15) and withdraw clamp screw (QR13 and QR14) from motor base. Assemble the motor to the motor base ensuring that faces A and B are parallel and the dimensions given are not exceeded (Figs. 7 and 8).
- h** Insert the plain end of the motor base swing pin in to the left hand $\frac{3}{8}$ " bore near the lower end of the countershaft arm. Hold the motor and base assembly in position, with the base plate uppermost and, rotating the swing pin so that the flat on it will line up with the 2 B.A. socket set screw in the motor base, pass it through both bearings of the motor base and into the right hand bearing in the countershaft arm. Position the swing pin so that the $\frac{1}{4}$ " B.S.F. half dog point socket set screw (QR11) in the left hand bearing of the countershaft arm can be inserted into the annular groove in the swing pin. Tighten the 2 B.A. cup point socket set screw (QR10) in the left hand bearing of the motor base to secure the latter to the swing pin. Check that the motor base and swing pin are free to rotate. Adjust the $\frac{1}{4}$ " B.S.F. peg end socket set screw if necessary.
- i** Still looking on the rear of the machine, fit the motor base clamp pin (QR13 and QR14), entering it from the right hand side, first through one of the tie bars, then through the motor base, finally through the second tie bar. Fit the washer and nut on the left hand end (Fig. 9).




Fig. 9




Fig. 10

- j** Mount the primary drive belt guard in position, attaching it by means of the $\frac{1}{4}$ " B.S.F. x $1\frac{1}{2}$ " cap screw and washer (QR41 and QR45) in the forward, lower slot. This screw is threaded into the hole provided in the countershaft arm. The $\frac{1}{4}$ " B.S.F. x $\frac{3}{4}$ " hexagon head screw (QR40) is used in the upper slot with one washer (QR15) on each side of the backplate. This screw is threaded into the end of the swing head pivot shaft (4) from which it was removed before the shaft was fitted. (See paragraph E.) Position the backplate so that the screws are about two thirds of the way along their slots, the backplate being near its forward position. Tighten the lower screw securely first. Now tighten the upper screw to draw the swing head pivot shaft through its bearings. Next, tighten the $\frac{1}{4}$ " B.S.F. cup point socket set screw in the countershaft arm to lock the pivot shaft. (Fig. 10)
- k** Replace the Woodruff key in the $\frac{3}{8}$ " diameter portion of the countershaft (6) and mount the two step pulley (7) on to the shaft, the longer boss first. Press the pulley firmly against the shoulder on the shaft and lock the securing screw tight.

Enter the shaft through the left hand swing head bearing (looking on the front of the machine), place the collar (9) on to the shaft (socket set screw to the right hand end) and push the shaft through so that the four step vee cone pulley (8) can be mounted on with the small step to the left. Push the pulley as far as it will go to the right and continue to feed the shaft through until the Woodruff key can be inserted into its keyway. Line up the key with the keyway in the pulley, push the pulley to the left and the shaft through the pulley. Place the vee belt in position over the shaft. Push the shaft through into the right hand bearing.

With the boss of the two step pulley (7) against the face of the swing head bearing position the collar so that the shaft has approximately 0.005" (0.1 mm) end float and the socket set screw will bear on the flat on the shaft. Tighten the screw to lock the collar in position. Again holding the 'straight edge' firmly against the left hand side of the headstock vee cone pulley (Fig. 6) push the countershaft vee cone pulley up to it and lock in position with the socket set screw.

l Release the belt tension (lever upwards and forwards) and place the vee belt in matching steps of the cone pulleys. Push the lever backwards and downwards to tension the belt. Check the belt tension which, having been set at the factory, should be correct. If, however, any adjustment is required, adjust the tensioning screws (QR28) until the slack of the belt allows approximately $\frac{1}{2}$ " total movement when lightly oscillated by the thumb and forefinger (Fig. 11). This will give an initial setting which can be increased if slip is experienced when the machine is operated.




Fig. 11




Fig. 12

- m** Place the motor pulley in position on the motor shaft with the larger diameter outwards, but do not secure. Holding a 'straightedge' firmly against the two step countershaft pulley, line up the motor pulley to it, checking that the face of the motor pulley is parallel to it. (Fig. 12.) If it is not, it will be necessary to reposition the motor on its base. When the pulleys are in line, lock the socket set screw to secure the motor pulley.
- n** Place the headstock belt guard (11) in position and adjust the pivot screws (QR58). Remove all traces of play but do not overtighten, as this would strain or even crack the guard. N.B. To obtain access to the left hand screw (looking on the front of the machine) through the hole provided in the motor drive guard backplate, the latter may have to be temporarily repositioned. Next, remove the split pin, which was inserted during packing, to release the roller and plunger assembly.
- o** Release the motor base clamp and the belt tension release and fit the motor drive vee belt. Push the belt tension release lever backwards and downwards to the stop. Tension the motor drive belt by allowing it to take almost the full weight of the motor and retighten the clamp.
- p** Check the position of the motor drive belt guard and adjust as necessary to give adequate clearance when the belt is both the slow and fast countershaft speed position, also pulley clearance when the belt tension release lever is in the released position. N.B. When changing the motor drive vee belt from one step to the other, the belt tension lever should be in the released position.
- q** Slide the tailstock on to the bed from the end. The clamp plate should be guided into position between and below the shears. The clamp lever should be in the free position, that is, roughly horizontal, pointing towards the end of the bed.

ASSEMBLY OF MOTORISING EQUIPMENT (Machine fitted countershaft clutch)

- a Proceed as at a, b, c, d and e on page 5.
- b Mount the primary drive belt guard as at j on page 6.
- c Remove the tape from the end of the countershaft and check that the steel ball and push bar (Q116 and Q117) are in position, the ball in first and the push bar projecting. Insert the countershaft (shaft, primary drive pulley, clutch, assembly) into the left hand bearing of the swing head (looking from the FRONT of the machine). When the shaft is projecting through the bearing, place in position, first the three parts of the ball thrust bearing (Q99) then the collar (Q100). Spring open the cir-clip (Q101) and slip it over the shaft (Fig. 13).
- d Place the pulley, with the vee belt in one of the grooves, on the shaft and push the shaft to the right (looking from the FRONT). Before easing the shaft into the right hand bearing, check that the Vee belt and Push Bar are both in place.




Fig. 13

Fig. 14

With the clutch operating lever and knob (Q94) in the position shown in Fig. 14 and the pulley as far to the right as possible, push the shaft through. When the Keyway in the shaft becomes fully exposed rotate the pulley to line up the Keyways and insert the Woodruff key, ensuring that the cir-clip is to the left of it. Push the shaft through as far as it will go and locate the cir-clip in the groove provided. N.B. Any other position of the clutch operating lever will prevent the shaft from taking up its correct position, consequently the cir-clip will not enter its groove.

e To ensure the correct alignment of the countershaft and headstock spindle pulleys, place a straightedge across the face of the headstock pulley and adjust the position of the countershaft arm so that the headstock and countershaft cone pulleys are parallel. See Fig. 14. N.B. During this operation it may be necessary to adjust the position of the countershaft cone pulley, as well as the position of the countershaft arm to ensure correct alignment.

After setting, tighten the four hexagon head screws which secure the countershaft arm and the grub screw in the countershaft cone pulley.

f Before proceeding further with the assembly, check the clutch adjustment. See page 24.

g With the belt tension lever in the released position, adjust the position of the inner hexagon nut on the 1/2" B.S.F. stud at the bottom of the countershaft arm, so that the washer is just trapped finger tight. Over tightening will cause straining so that misalignment of the headstock may ensue if the headstock is jolted at some future date. Replace the outer washer and the outer hexagon nut on this stud and lock tight.

h Position the headstock drive belt so that it is in matching grooves of the headstock and the countershaft vee cone pulley. Push the cam backwards and downwards against the stop so that the camshaft is in the full lift position. Check the belt tension which should be correct, having been set at the factory, but if any adjustment is required, adjust the tensioning screws (Q57) until the slack of the belt allows approximately 3/8" total movement when lightly oscillated by the thumb and forefinger. See Fig. 11. This will provide an initial setting which can be increased if slip is experienced when the machine is operated.

i Assemble the motor to the motor base and these to the countershaft arm at the same time fitting the motor base clamp pin, as at g, h and i on page 6. See also Figs. 7, 8 and 9.

j Mount the motor pulley on to the motor shaft, and line up; mount the headstock belt guard; adjust the primary drive belt tension; position the motor drive belt guard; slide the tailstock onto the end of the bed; all as paragraphs m, n, o, p and q on page 7.

FOUNDATION

It is essential that the Lathe be placed on a solid foundation. The floor material is an important consideration, concrete being the most satisfactory. If the floor is of flimsy construction, a possible solution is to cut a hole through the floor and build up a concrete foundation from the ground up to the floor level.

If the machine is to be located on an upper floor of timber construction, it should be placed directly over a beam or girder, near a wall, or at some other spot where displacement of the floor will be at a minimum.

Floor Stands

The MYFORD steel cabinet stand makes an ideal support for the Lathe. See Figs. 15, 16 and 17. Wooden benches are not recommended, as they are affected by moisture and atmospheric changes. Despite the rigidity of the Lathe a warping bench can upset the level of a Lathe in the space of a few days, and greatly impair its accuracy.




Fig. 15. Lathe mounted on Industrial Cabinet Stand with built-in coolant service.




Fig. 16. Tray-top Cabinet with deep tray, raising blocks and terminal block only.




Fig. 17. Tray-top Cabinet as Fig. 16 but with drum type switch.

MYFORD ML7-R 3½" CENTRE LATHE

If the user is compelled to use a wooden bench, good dry timber must be used. The structure should be solidly built, well braced and should be securely bolted to the floor. A piece of steel sheet should be placed on the bench top to prevent the Lathe feet from sinking into the wood surface under the bolting down pressure. The MYFORD drip tray see Fig. 18, will serve very well for this purpose.




Fig. 18. Drip Tray.

Lathe Height

A bench height of 33-34 inches is suitable for the man of average height. Alternatively, a comfortable working height can be gauged by arranging the Lathe so that the upper surface of the topslide is at elbow height.

Before bolting down, the floor stand should be packed under the feet until the top surface is roughly level.

Levelling the Lathe

If the Lathe is not properly levelled, the Lathe bed may be twisted, resulting in misalignment of the headstock or tailstock with the ways, causing the lathe to turn and bore taper. ACCURATE WORK CANNOT BE EXPECTED IF THE LATHE IS NOT LEVEL.

The precision built into a Lathe can be completely nullified by faulty, uneven bolting on bench or floor stand.

Levelling should be carried out by placing shims of thin metal or asbestos sheet jointing under the Lathe feet, the amount of packing being determined with an Engineer's precision level. Where the Lathe is mounted on raising blocks having jackscrews, packing shims are not required. The level, which should be sufficiently sensitive to read to .003 per foot or better, should be placed across the bed at both the headstock end and the tailstock end. See Fig. 19. After bolting down re-check for level, and make any further necessary adjustments.

Do not try to level the Lathe by packing under the cabinet or bench.




Fig. 19

MYFORD ML7-R 3½" CENTRE LATHE

Levelling with a Dial Test Indicator

If a precision level is not available, use a dial test indicator in the following manner, to ensure that no distortion of the lathe bed takes place when bolting down:—

Place the Lathe on the bench or floor stand with the holding down bolts loosely in position.

Grip a piece of 1" diameter material in the chuck with approximately 8" protruding, and clamp the dial indicator in the tool post with the plunger located at the extreme end of the test bar as shown in Fig. 20.




Fig. 20

Showing test piece in chuck and dial indicator in tool clamp.

Rotate the headstock spindle by hand, and adjust the dial indicator, so that the zero mark lies midway between the extremes of the pointer movement.

So long as the lathe bed is not strained the dial indicator will continue to register zero but any distortion due to bolting down on to an uneven surface will be shown immediately by the dial indicator.

The lathe feet should be shimmed, so that, when the holding down bolts are finally tight, the dial indicator still reads zero.

Checking the Levelling

A final check of the levelling can be carried out by turning a test piece as shown in Fig. 21. The test piece should be approximately 1" dia. by 4" to 6" long and should be relieved in the middle so as to leave about ⅜" for test turning at each end.

Take a very light finishing cut (.002") across both collars, without the use of the tailstock and without alteration of the tool setting. Measure the dia. of each collar with a micrometer. The collars should be the same dia., if not the same, a further adjustment of the packing is required.

If the dia. of the test piece is larger at the free end, packing should be increased under the FRONT of the foot at the tailstock end, or under the BACK of the foot if smaller.




Fig. 21
Showing test piece with two collars.

Readjustment

It may be necessary to readjust the packing shims from time to time, especially if the lathe is mounted on a wooden floor or bench.

Electric Motors and Switch Wiring

ML7-R Lathes are designed for use with 1,420/1,450 r.p.m. full load speed electric motors of 1/2 h.p. 3 phase and certain single phase of 1/4 h.p. Resilient mounted motors are recommended.

All single phase motors which are required for reversing duty will need to have four terminals for connection to the reversing switch. Should only two terminals be provided, it will not be possible to use the motor, unless the two wires which feed the motor starting windings can be brought out separately.

Switches

MYFORD cabinet stands are fitted with a reversing switch which is already connected to a terminal block at the back of the stand. See Figs. 22 and 23. The Lathe motor and mains supply should be connected to the appropriate terminals as indicated in Figs. 26 and 27. NOTE THE EARTHING TERMINAL TO THE LEFT OF THE TERMINAL BLOCK.

Stands (20/039 and 20/040) fitted push button starters

On stands fitted with push button starters the electricity supply must not be connected to the terminal block at the back of the Lathe but direct into the push button starter (for single phase connect to L1 and L3).




Fig. 22




Fig. 23

Close-up of terminal Block with and without cover.

The DRUM TYPE reversing switch, see Figs. 24 and 25 is the most suitable type of switch for use with a bench mounted Lathe, being completely shrouded and easily mounted. A mounting bracket is available for the attachment of the drum type switch to the front of the Lathe in a convenient operating position. See Fig. 25. This bracket can be fitted to standard change gear machines only.




Fig. 24
Drum Type Switch




Fig. 25
Drum Type Switch Mounted on Switch Bracket

The connections for drum type reversing switches are shown in Figs. 26 and 27. When single phase motors are supplied with Bench Lathes, but without switchgear, the terminals are 'bridged' at the MYFORD works for plain 'ON-OFF' starting. These bridge pieces must be removed before a reversing switch can be used. When a single phase motor is to be connected to a reversing switch **always check that there are no links** connecting the starting to the running windings.

Wiring diagrams for motors used in conjunction with Dewhurst drum type reversing switch.




Fig. 26. Single Phase.

For terminal markings for other makes of motor see page 14, Fig. 28.




Fig. 27. Three Phase.

Earthing

It is important to make sure that the cabinet and the Lathe are electrically connected to a satisfactory earthing point. Should any difficulty be found in wiring and running the motor the advice of an electrician who is competent in motor wiring should be sought.

MYFORD ML7-R 3½" CENTRE LATHE

Connection Diagram—Santon Rotary Reversing Switch

MOTOR	STARTING WINDING	RUNNING WINDING	RUNNING WINDING	STARTING WINDING
CROMPTON	Z	A	AZ	T
AEI	A1	T2	T3	A2
ELECTRIC	1	2	3	4
BROOK	Z1	A1	A2	Z2





Fig. 28

N.B. Fig. 26 shows terminal markings for Crompton motors. The table above shows alternative terminal markings—equally applicable when connecting other motors to drum type switches.



LUBRICATION CHART — except where otherwise specified use Esso Nuto H32 (I.S.O. Specification 3448/1975(E) — formerly Nuto H44)

1. **Countershaft bearings.** Replenish the two oil cups daily.
 2. **Headstock front bearing.** Replenish the oil cup twice daily.
 3. **Headstock rear bearing.** Lubricate with the oil gun daily.
 4. **Tumbler gear studs.** Lubricate with the oil gun twice daily.
 5. **Change wheel studs.** Lubricate with the oil gun twice daily.
 6. **Headstock pulley.** Lubricate with the oil gun twice daily whenever the reduction gear is in use.
 7. **Backgear spindle.** Lubricate with the oil gun twice daily whenever the reduction gear is in use.
 8. **Leadscrew brackets, L.H. & R.H.** Lubricate with the oil gun weekly.
 9. **Saddle, front shear.** Lubricate with the oil gun daily.
 10. **Saddle, rear shear.** Lubricate with the oil gun daily.
 11. **Apron reservoir.** Replenish with the oil gun daily. This lubricates the handwheel and rack pinion shafts, also the reduction gear.
 12. **Tailstock barrel.** Lubricate with the oil gun daily.
 13. **Tailstock thrust.** Lubricate with the oil gun daily.
 14. **Cross-slide and top slide ways.** Clean and apply an oil of viscosity S.A.E.30 weekly.
 - *15. **Cross-slide and top slide feedscrews.** Using oil of viscosity S.A.E.30 lubricate from underneath twice weekly.
 - *16. **Change gear teeth.** Lubricate with oil of viscosity S.A.E.30 daily.
 - *17. **Reduction gear teeth.** Lubricate with oil of viscosity S.A.E.30 daily whenever the reduction gear is in use.
 - *18. **Leadscrew.** Clean with a stiff brush and apply oil of viscosity S.A.E.30 weekly.
 - *19. **Rack.** Lubricate with oil of viscosity S.A.E.30 weekly.
- NOTE:** We supply and recommend Esso Nuto H32 (formerly Nuto H44) or equivalent for general lubrication. Where oil of viscosity S.A.E.30 is specified, any good motor oil of this number will be satisfactory. For starred items, nos. 15, 16, 17, 18 and 19, Rocol MTS1000 grease should be used in those territories where it is available.

MYFORD ML7-R 3½" CENTRE LATHE

LUBRICATION

After installing the Lathe, refer to the lubrication chart on pages 15 and 16 and treat all points with the recommended lubricants. An oil gun is supplied for use with the pressure nipples fitted to each machine. Careful attention should be paid to the lubrication of the headstock bearings, particularly during the first few hours of running.

Headstock Spindle

The front bearing is lubricated from the oil cup mounted on the front of the bearing housing. The cup should be replenished twice daily. The rear bearings require lubrication only once daily. A nipple is provided on the top of the rear bearing housing.




Fig. 29

Fig. 29 is a section through the headstock, showing No. 7 the Lubricator, No. 4 the Wick, No. 5 the Spring, No. 6 the Retaining Plug and No. 8 an 'O' Ring, all for the front bearing lubrication.

It will be observed that the end of the Wick is in contact with the spindle and it should be noted that the arrangement has been so designed that provided the oil cup is replenished twice daily adequate lubrication is provided right through the speed range.

Countershaft

The hardened steel countershaft runs in oil impregnated bronze bearings which are located in the swing head. Oil cups are provided for occasional lubrication. The countershaft clutch (if fitted) pulley is mounted on 'sealed for life' ball bearings which do not require any attention.

IMPORTANT: WHENEVER THE HEADSTOCK REDUCTION GEAR IS USED, ENSURE THAT THE HEADSTOCK PULLEY BEARING IS WELL LUBRICATED VIA THE OIL NIPPLE AT THE LARGE END OF THE PULLEY.

Fig. 30.




Fig. 30. Showing the oil nipple for headstock pulley bearing lubrication.

General

Daily cleaning and correct lubrication of the machine will greatly increase its working life. Excess oil should be wiped from oiling points, as oil and dirt form an abrasive compound which can easily damage precision bearing surfaces.

Wipe the bed and other sliding surfaces with a clean oily rag at frequent intervals. Use a brush to clean spindle nose threads, gear teeth, leadscrew threads etc.

At regular intervals, the leadscrew should be thoroughly cleaned with a stiff brush and paraffin, and oiled freely along its entire length.

Keep the Lathe completely covered between working periods. The MYFORD waterproof Lathe cover shown in Fig. 31 will provide excellent protection when the Lathe is not in use.



Fig. 31. Lathe cover.

CONTROLS & ADJUSTMENTS

DO NOT OPERATE THE LATHE until all the following instructions have been carefully read and the controls and adjustments are fully understood.

Headstock Spindle Drive

The vee cone pulleys on the motor, countershaft and headstock spindle in conjunction with the reduction gear, give a range of 14 speeds. Fig. 32.

The two fastest background speeds are approximately the same as the two slowest ungeared speeds. They are not shown and should not be used.




Fig. 32

Headstock Spindle Speeds (1420/1450 R.P.M. Full Load Speed Motor)				
Spindle Speeds with 1750 R.P.M. (60 Hz A.C.) Motor in Brackets				
Motor Drive Belt Position	Headstock Drive Belt Position	Ungeared	Geared	
A	1	2105 (2525)	—	
A	2	1480 (1775)	—	
A	3	1050 (1260)	135 (162)	
A	4	740 (890)	95 (114)	
B	1	600 (720)	77 (92)	
B	2	420 (505)	54 (65)	
B	3	300 (360)	39 (47)	
B	4	210 (250)	27 (32)	

MYFORD ML7-R 3 1/2" CENTRE LATHE

Speed Changing

Access to the headstock belt for speed changing is attained by lifting up the front guard, as shown in Fig. 33 and the headstock belt tension is released by the operation of the belt tensioning lever.

DO NOT ATTEMPT TO CHANGE THE HEADSTOCK BELT POSITION WHILST THE LATHE IS RUNNING, NOR WITHOUT OPERATING THE BELT TENSIONING LEVER

The six lower speeds of the available range of 14 spindle speeds are achieved through the headstock reduction gears. As supplied, the machine is set for direct (or ungeared) drive, i.e. the headstock cone pulley is coupled to the 60T 'bull' gear which is in turn keyed to the spindle.

To engage the reduction gears release the pulley coupling by rotating the half circular key (fitted to the 60T 'bull' gear) through 180 degrees. The two positions of the key operating lever are positively determined by ball and spring.

Release the plunger which locates the reduction gear lever and reset in the upper position to engage the reduction gear cluster with the 60T 'bull' gear and the cone pulley sleeve gear.




Fig. 33. Location of the Headstock Controls.

- (1) BELT TENSION RELEASE LEVER
- (2) LEVER FOR BACK GEAR KEY
- (3) BACK GEAR LEVER
- (4) TUMBLER REVERSE LEVER

DO NOT ATTEMPT TO ENGAGE THE REDUCTION GEARS WHILST THE SPINDLE IS REVOLVING

MYFORD ML7-R 3 1/2" CENTRE LATHE

Adjustment of reduction gear cluster engagement

Release the headstock pulley coupling and engage the reduction gear cluster. Place a wedge between the reduction gear cluster (1) and the inside of the headstock casting, as shown in Fig. 34. This will load the eccentric shaft (2) and so prevent movement.




Fig. 34. Showing reduction gear adjustment.

Release the lever securing screws (3 and 4) and withdraw the lever plunger (5). Adjust the lever in relation to the eccentric shaft and tighten the securing screws. Remove the wedge, restore the lever plunger and check the backlash.

Replacement of reduction gear cluster

Remove circlip (parts list H77) which retains gear cluster. Release securing screws (Fig. 34, Nos. 3 and 4), withdraw plunger (5) and remove back gear lever. Withdraw 2 B.A. socket set screw (parts list H26) at front end of headstock, which was partially obscured by backgear lever, also the retaining screw (H71), which is inserted through the upper hole for the plunger for the back gear lever. Withdraw eccentric (H78).

Headstock spindle bearings

IMPORTANT—The bearings are carefully adjusted at the works and should not be interfered with unless adjustment is necessary. Damage can be caused by faulty adjustment and the following notes and drawings should be carefully studied before attempting adjustment.

As shown in Fig. 35 the headstock bearing layout combines a tapered front journal with twin angular contact ball bearings at the rear. Front journal clearance is adjusted by axial movement of the spindle relative to the tapered bush.

In considering the ball bearings it will be noted that the outer races of each bearing are separated by a spacing washer, and that both outer races and spacer are therefore capable of, and intended to be, locked solid together by screwed rings, Nos. (1) and (2). As the inner races have no spacer they can be loaded by end pressure arising from the adjustment of collar (No. 4).

(Note. The spacing washer is cut away to permit oil to reach the ball bearings. Should the bearings be removed from the headstock care must be taken when replacing to ensure that this cut-away section is opposite the oil nipple.)

Examination of Fig. 35 will show that the ball bearings are held between the spindle thrust shoulder (5) and the adjusting collar (4), by the distance sleeve (6) and the sleeve gear (7) which act as spacers.




Fig. 35. Showing headstock spindle layout.

It follows that any axial displacement of the ball bearings will result in a similar displacement of the spindle. This in turn will affect the radial clearance between the tapered front journal (8) and the bronze bush (9). The externally screwed rings (1) and (2) permit very fine axial setting of the spindle with resulting critical control over front journal clearance.




Fig. 36

ADJUSTMENT OF SPINDLE BEARINGS

1. To free spindle from front bush
Rotate locking ring (1) using the 'C' spanner provided, the top of the locking ring being turned towards the operator. Rotate locking ring (2) in the same direction until the ball bearings contact the locking ring (1) and the outer races are again locked together. This procedure moves the ball bearings and spindle bodily forward to a position free of the front bush as shown in Fig. 37.

IMPORTANT. Adjustment of rear ball bearings for correct loading cannot be made until the spindle is completely freed from the front bush. Please note that all threads are right hand.




Fig. 37. Showing spindle movement exaggerated.

2. Loading the rear ball bearings

Refer to Fig. 35. Slacken screw (3) just sufficiently to allow adjusting collar (4) to be turned. Excessive freedom in the collar thread may allow the thrust face to move out of square and affect the setting of the ball bearings when the screw (3) is tightened. Rotate collar (4) clockwise (looking on end of spindle) to increase the loading.

3. Adjusting the front bearing

The correct clearance between the spindle cone and tapered bronze bush can now be restored. Move the ball bearings and spindle back until the spindle cone contacts the tapered bush and will not rotate, i.e. to a condition of no clearance. Clearance can now be set by moving the spindle forward from this 'solid' position by a 1/4 in. rotation of the rim of the locking rings (i.e. 15 degrees). This provides a preliminary setting which may be varied according to running conditions.

Note. The ball races should not be loaded more than is necessary to remove all traces of spindle end play. **OVERLOADING WILL CAUSE RAPID DETERIORATION OF THE SPINDLE BEARINGS.** The races are a close fit on the spindle and, should collar (4) be overtightened, it may be necessary (after slackening) to tap the end of the spindle lightly to ensure that the ball races regain a free position.

MYFORD ML7-R 3 1/2" CENTRE LATHE

Clutch (if fitted)

Reference to Fig. 38 will show that the countershaft clutch consists of a coned metal driving member, the clutchplate (3) which is tenoned into the end of the countershaft, and normally held in engagement with the tapered cone of the pulley (4) by a compression spring (6) which is inserted into the hollow countershaft (7) between the shoulder in the bore of the shaft and the head of the push rod (1).




Fig. 38. Showing countershaft clutch layout.

The clutch is engaged or disengaged by rotation of the cam shaft assembly (10). Scrap Section A-A on the illustration shows that this has two flats machined on it. The larger flat corresponds to the engaged position of the clutch (lever knob close to headstock belt drive guard) and the smaller one, to the disengaged position (lever knob moved to the right). The flats operate on the push bar (9), thence to the push rod (1) via the steel ball (8).

During the early life of the machine, a certain amount of bedding in takes place between the clutch plate and the pulley, and it may be necessary to reset the push rod (1). This is screwed into a threaded hole in the clutch plate, and secured by the hexagon nut (2).

The clutch is correctly adjusted when there is 0.005" to 0.010" clearance between the push bar (9) and the larger flat on the cam shaft lever assembly (10), with the clutch engaged. (Approximately 45° to 90° rotation of the push rod from the 'no clearance' setting.) This clearance may be obtained by releasing the hexagon nut (2) and rotating the push rod (1), relative to the clutch plate (3), clockwise to reduce the clearance, and anti-clockwise to increase the clearance. (Play in operating lever about 5").

N.B. The ball bearings in the pulley (4) are 'sealed for life', are pre-packed with grease, and do not need further lubrication. The hardened countershaft runs in 'Oilite' bearings. Oil is fed to the OUTSIDE of these bearings via the oil cups (Section Q, Part No. 7). They should be filled at regular intervals with Esso Nuto H32 Oil or equivalent. The ball thrust bearing (5) will be lubricated by 'Surplus' oil from the left hand countershaft bearing.

Tumbler reverse

The Tumbler Reverse or Leadscrew Reverse gear, provides a quick means of changing the rotation of the leadscrew drive to reverse the direction of travel of the lathe carriage. The central lever position is neutral and disengages the leadscrew drive.

Reference to Fig. 39 will show that the tumbler reverse assembly is supported on the headstock by a long swivel pin (1) which is a press fit in the tumbler reverse lever (2). The assembly is retained in position by the thrust screw (3) which draws the tumbler reverse lever back against the pivot boss facing on the headstock.

NOTE. It is important that the thrust screw (3) be set with light pressure only. Heavy pressure may extract the swivel pin (1) from its position in the tumbler reverse lever.




Fig. 39

Carriage controls

Fig. 40 gives the names and positions of the carriage controls. The apron handwheel moves the carriage along the bed, and the cross slide and top slide ball handles move the tool post in and out.

The cross slide feedscrew dial graduations represent slide movements in increments of .001", whereas the topslide is graduated in increments of .002".

On machines fitted with metric feedscrews, each division of the micrometer dial on the cross slide represents 0.05 mm off work diameter, and on the top slide, 0.05 mm movement.




Fig. 40. Showing the carriage controls.

- (1) Cross-slide ball handle
- (2) Cross-slide micrometer dial
- (3) Topslide base graduations
- (4) Topslide base clamp bolt (2)
- (5) Tool clamp
- (6) Topslide micrometer dial
- (7) Topslide ball handle
- (8) Saddle clamp
- (9) Cross-slide locking screw (2)
- (10) Thread dial indicator mounting point
- (11) Apron handwheel
- (12) Leadscrew nut lever

MYFORD ML7-R 3 1/2" CENTRE LATHE

MYFORD ML7-R 3½" CENTRE LATHE

A clamp screw (8) is provided on the saddle to lock the carriage to the bed for facing, parting off, and milling etc., CARE SHOULD BE TAKEN TO SEE THAT THE CLAMP SCREW IS NOT TIGHTENED WHEN THE CARRIAGE IS TRAVERSED BY THE LEADSCREW.

Two socket set screws, (9) on Fig. 40, visible on the parts list as C71, are fitted to provide cross slide clamping. (The two which project app. $\frac{1}{4}$ "). This gives extra rigidity when carrying out certain milling and boring operations.

Longitudinal Feed

Depress the half-nut lever to engage the half nuts with the leadscrew when longitudinal movement of the carriage is required.

If the half-nuts do not engage immediately, DO NOT USE FORCE. Wait until the leadscrew rotates to a position which permits engagement of the half-nut by gentle pressure only.

The thread dial indicator will give visual guidance and show when the leadscrew is in the correct position for nut engagement.

Saddle and Slide Rests

All slides are provided with normal gib adjustment, and steel plates are fitted beneath the saddle to prevent saddle lift. These plates bear on the underside of the lathe bed and adjustment to ensure close contact is by means of laminated shims. These have a solid appearance, but are made up of 0.002" laminations. By inserting a pen-knife blade it is an easy matter to peel off the desired thickness to allow the strips closer contact with the lathe bed.

The saddle and compound slides on a centre lathe are designed to withstand the cutting force of the tool and it is therefore necessary to maintain, by periodic adjustment, the close contact of gib strip and slide surface. Careful attention should be given to the screw adjustment to ensure an even pressure of the gib strip.

When stripping the compound slides for thorough cleaning and lubrication re-adjust the slides without feed screws and screw support brackets, testing the slides by hand motion, re-assembling the feed screw units as the last operation. By the very fact that the slides are built upon each other deflection of the turning tool is transmitted through the slides; so it is important to see that your lathe tool has the minimum overhang and is flat on its clamping surface.

Saddle Gib Strip Adjustment

When adjusting the saddle gib strip, first adjust the two outer screws, ensuring equal pressure. After tightening the locknuts, check for freedom of movement but without play. Next, adjust the inner screws, so that they contact the strip without increasing the friction and tighten their locknuts.

Apron

The apron is anchored to the saddle by means of four socket head screws, and a periodic check should be made to ensure that these screws are tight.

The 2 B.A. x 1½" cap screw (parts list, L14) must be so adjusted that the leadscrew nut will not close sufficiently to cause it to bind on the leadscrew.

The Tailstock

The Tailstock is securely locked to the bed by the quick-acting clamp lever which is located at the rear of the tailstock, Fig. 41.

The barrel is locked in place by means of the thumb lever, also at rear.

The Tailstock can be set-over $\frac{7}{16}$ " for taper turning, by first loosening the bed clamp and then adjusting the screws which are located in the tailstock body, directly above the base tenon. A zero mark is engraved at the end of the tailstock to serve as a rough guide to set-over amounts, and to assist in returning the tailstock to its normal position for parallel turning.




Fig. 41. Rear view of the tailstock.

- (1) CLAMP LEVER
- (2) BARREL LOCKING LEVER
- (3) GIB SECURING SCREWS
- (4) GIB THRUST SCREWS
- (5) SET OVER SCREW

Tailstock Gib Adjustment

Refer to Fig. 42. Release gib securing screws (1) and retighten until just nipped. Adjust thrust screws (2) just sufficiently to remove all trace of play of the tailstock relative to the bed shears, but without causing undue friction. Retighten gib securing screws and check for freedom of movement but lack of 'play'.




Fig. 42

MYFORD ML7-R 3 1/2" CENTRE LATHE

Power Carriage Feeds

Standard change gear lathes are equipped with a set of 14 change wheels for cutting various screw threads and obtaining various power longitudinal feeds. To set up the lathe for threading or feeding, refer to the change wheel chart inside the change wheel guards Figs. 44 and 45.




Fig. 43. Showing Leadscrew Drive.

- (1) TUMBLER REVERSE LEVER
- (2) TUMBLER REVERSE GEARS
- (3) 30T SPINDLE GEAR
- (4) TUMBLER SLEEVE GEAR
- (5) 1st STUD GEARS
- (6) 2nd STUD GEARS
- (7) LEADSCREW GEAR
- (8) SPACER

The thread pitch, or feed, to be set up will be located in the first two columns under the headings T.P.I. and Feed per Rev. In the third column under the heading DRIVER is listed a number of teeth in the change wheel which should be placed on the tumbler sleeve gear.

In the fourth and fifth columns under 1st stud and 2nd stud are shown the gears or pairs of gears which should be placed on the 1st and 2nd studs respectively.

The sixth column lists the gear to be placed on the leadscrew under the heading LEADSCREW.

The column headed SET-UP refers to the number of the diagram, Fig. 46, which will indicate the arrangement of gears and spacers for the pitch in question; see also Fig. 43 which shows set-up as in Diagram 3, Fig. 46.

When setting up the gear train sufficient backlash between each pair of meshing gears should be allowed. When the lathe is in operation the play in the gears is automatically taken up according to the direction of travel; the amount of gear clearance does not influence the accuracy of thread cutting. Gear noise can be reduced by the application of grease, preferably graphited.

MYFORD ML7-R 3 1/2" CENTRE LATHE

INCH PITCHES Fig. 44

T. P. I.	FEED PER REV.	DRIVER	1ST. STUD DRIVEN	2ND. STUD DRIVEN	LEAD SCREW	SET - UP
8	.1250	20	IDLE 75 WHEEL		20	1
9	.1111	40	IDLE 60 WHEEL		45	1
10	.1000	40	IDLE 60 WHEEL		50	1
11	.0909	40	IDLE 60 WHEEL		55	1
12	.0833	40	IDLE 60 WHEEL		60	1
14	.0714	20	IDLE 70 WHEEL		35	1
16	.0625	20	IDLE 70 WHEEL		40	1
18	.0556	20	IDLE 70 WHEEL		45	1
19	.0526	40	38 20	IDLE 55 WHEEL	50	2
20	.0500	20	IDLE 70 WHEEL		50	1
22	.0455	20	IDLE 70 WHEEL		55	1
24	.0417	20	IDLE 70 WHEEL		60	1
25	.0400	40	50 30	IDLE 45 WHEEL	75	2
26	.0385	20	IDLE 70 WHEEL		65	1
28	.0357	30	35 20	IDLE 50 WHEEL	60	2
32	.0313	30	40 20	IDLE 55 WHEEL	60	2
36	.0278	30	45 20	IDLE 55 WHEEL	60	2
40	.0250	30	50 20	IDLE 55 WHEEL	60	2
44	.0227	20	55 30	IDLE 50 WHEEL	60	2
46	.0217	20	46* 30	IDLE 45 WHEEL	75	2
48	.0208	20	60 35	IDLE 45 WHEEL	70	2
54	.0185	20	45 20	IDLE 55 WHEEL	65	2
60	.0167	20	50 25	IDLE 55 WHEEL	75	2
64	.0156	35	40 20	60 30	70	3
72	.0139	25	50 30	45 20	60	3
80	.0125	25	50 35	70 30	75	3
88	.0114	30	40 25	55 20	75	3
92	.0109	20	46* 30	50 20	60	3
96	.0104	30	40 20	60 25	75	3
104	.0096	20	50 30	60 25	65	3
	.0087	20	55 30	60 25	65	3
112	.0089	25	50 30	60 20	70	3
120	.0083	20	50 30	60 25	75	3
	.0058	20	55 25	60 20	65	3
	.0043	20	60 25	65 20	75	3
	.0037	20	65 25	70 20	75	3
	.0018	12*	65 20	70 20	75	3

LEADSCREW 8 THREADS PER INCH
 ● Not a Standard Gear. Available as an extra.
 ★ 12/30 tooth fine feed tumbler cluster gear (1974A) available as an extra.

The tumbler reverse lever should not be shifted during thread cutting operations, as such movement may alter the position of the headstock spindle relative to the leadscrew, thereby causing split threads.




Fig. 46

METRIC PITCHES Fig. 45

FEED PER REV. MILLIMETERS	DRIVER	1ST. STUD DRIVEN	2ND. STUD DRIVEN	LEAD SCREW	SET - UP
0.20	21*	50	30	60 21*	70 3
0.25	30	40	21	60 21	70 3
0.30	21	60	45	50 21	70 3
0.35	35	40	21	50 21	70 3
0.40	21	50	21	IDLE 60 WHEEL	2
0.45	45	40	21	50 21	70 3
0.50	21	50	45	40 20	60 3
0.60	21	50	45	40 30	75 3
0.70	21	50	21	IDLE 60 WHEEL	40 2
0.75	45	40	35	50 21	70 3
0.80	21	50	45	IDLE 40 WHEEL	75 2
0.90	45	25	21	40 21	70 3
1.00	45	40	21	IDLE 50 WHEEL	75 2
1.10	45	50	35	40 21	75 3
1.20	45	25	30	50 21	60 3
1.25	45	40	21	IDLE 50 WHEEL	60 2
1.30	65	25	21	40 21	70 3
1.40	45	25	35	50 21	60 3
1.50	21	50	45	IDLE 35 WHEEL	40 2
1.60	45	25	21	IDLE 55 WHEEL	75 2
1.75	30	40	25	50 21	60 3
1.80	30	40	45	25 21	50 3
2.00	60	40	21	IDLE 55 WHEEL	50 2
2.25	45	40	60	40*	21 50 3
2.50	45	30	21	IDLE 50 WHEEL	40 2
2.75	55	20	30	40 21	50 3
3.00	45	25	21	IDLE 60 WHEEL	40 2
3.50	60	20	35	40 21	50 3

Thread Dial Indicator




Fig. 47—Thread Dial Indicator Mounting

Every lathe is provided with a machined facing on the right hand side of the apron, drilled and tapped ready to receive this unit. Provision is made for the alignment of the dial markings with the zero mark on the indicator body as shown in Fig. 47. The indicator can be readily engaged or disengaged, and operates as follows:—

- (1) For even number threads the clasp nut can be engaged at any numbered mark on the dial.
- (2) Odd number threads should always be engaged at the same number or any alternate number.
- (3) For half threads per inch, always engage the same number.
- (4) For other threads, m/m sizes, etc., it is recommended that the clasp nut should not be disengaged.

Note. Threads that are exact multiples of the leadscrew pitch (8 T.P.I.) do not require the use of an indicator.

Replacement of Headstock Vee Belt

In order to change the vee belt it is necessary partially to dismantle the countershaft and headstock spindles. Both spindles must be withdrawn from their respective bearings sufficiently to allow removal of the vee belt.

The headstock ball bearings are arranged with an interference fit on the spindle diameter. Reassembly will be greatly facilitated if the appropriate portion of the spindle is greased before introduction to the ball bearings.

Countershaft (standard — without clutch)

For both dismantling and reassembly, reference should be made to paragraph 'K' on pages 6 and 7 under 'Assembly instructions of motorising equipment (standard machine)'.

With the belt tension released, open the primary drive guard. Release the socket set screws securing the countershaft vee cone pulley and the collar QR35. Push the vee cone pulley to the right and rotate the shaft so that the Woodruff key can be withdrawn. Move the cone pulley to the left and withdraw the shaft a sufficient distance to the left to enable the old belt to be removed and the new one fitted over the countershaft. Reassemble and adjust as at paragraph 'K' on page 7.

Countershaft Clutch Unit (if fitted)

For both dismantling and reassembly reference should be made to Fig. 38 on Page 24 and paragraphs 'c' and 'd' on Page 8 under 'Assembly of motorising equipment'.

With the primary belt drive guard open and belt tensioning lever in the released position, release the grub screw securing the countershaft cone pulley and rotate the shaft so that the key is near the top but towards the front. Slide the pulley to the right and remove the Woodruff key. Ease the circlip (to the right of the left hand bearing) from its groove. Withdraw the shaft complete with clutch and two step pulley, to the left, far enough to enable the old belt to be removed and the new one to be fitted. Reassemble as described in paragraphs 'c' and 'd' on Page 8. Line up the countershaft vee cone pulley as in Fig. 14, Page 8.

Headstock Spindle

Before attempting to dismantle the headstock spindle, remove the grub screw at the front end of the headstock below the main spindle and insert a suitable pointed pin (approximately 1/16") into the hole so that it passes completely through the Wick. This will ensure that the Wick is not forced upwards through the bearing by the compression spring below it, and will facilitate subsequent replacement of the spindle.

First read the description and instructions with regard to **Adjustment of Spindle Bearings** (pages 22 and 23) which will provide detailed information on the construction and operation of the headstock spindle.

Spindle Withdrawal. Refer to Fig. 35. Slacken screw (3) just sufficiently to allow adjusting collar (4) to be turned.

Remove adjusting collar.

Withdraw sleeve gear (7) and remove Woodruff key.

Release the screw securing the 60T backgear to the spindle.

Tap out the spindle in the direction towards the tailstock until it is free of the interference fit in the rear ball bearings.

Complete the withdrawal of the spindle and remove the pulley and 60T backgear, which should be held together as a single unit. The distance sleeve (6) should be left in position, supported by the bore of the screwed ring (1).

Remove and replace vee belt.

Reassemble.

Adjust the bearings as per the instructions on Pages 22 and 23.

Set the 60T backgear in the axial position which allows approximately .005" end play between the cone pulley and the distance sleeve (6).

Chuck Fitting

- (1) Before screwing backplate on to spindle nose, ensure the cleanliness of spindle nose, backplate register faces and thread.




Fig. 48

- (2) Screw backplate firmly on spindle nose.

- (3) Machine register diameter to light tap fit in chuck body.

Note.—With three-jaw gear scroll chucks, contact is made with the outer face of the chuck body and clearance with the inner face, see Fig. 48.

With four-jaw independent chucks, contact is made with the inner face of the chuck body, see Fig. 49.

With 6" four-jaw independent chucks contact is also made with the inner face of the chuck body but the threaded portion of the backplate is housed in the chuck body to minimise chuck overhang, see Fig. 50.




Fig. 49

- (4) Remove backplate from spindle nose. Mark out and drill clearance holes for three-jaw chuck locking bolts, and core diameter tapping holes for four-jaw chuck locking bolts. Remove all burrs with countersink or scraper. Care should be taken when marking out the holes to ensure clearance between the bore of the hole and bolt stem. With the four-jaw chuck backplate, the drilling centres can easily be marked by means of a centre punch with the shank diameter acting as a guide through the chuck body holes. After centring one hole, drill, tap and lock the backplate lightly with a locking bolt. The other three holes can then be centred without fear of the backplate shifting.




Fig. 50

- (5) When tightening locking bolts, apply pressure evenly and gradually to all four in rotation.

Chuck Backplates and Threaded Body Chucks

Register bores are held to very close limits. When backplates or threaded body chucks are supplied as separate units after the machine has left these works the register bore may need very light scraping or polishing with fine emery cloth.

Do not screw equipment on to the spindle nose without ensuring that the spindle register diameter is lightly smeared with fine oil.

INSTRUCTIONS FOR ORDERING REPLACEMENT PARTS

The following information should be supplied with the order:—

1. Type and Serial Number of the lathe, and in the case of lathes with gearboxes fitted, also the serial number of the gearbox.
2. Section letter and drawing reference numbers of part as listed.
3. Quantity required.




Fig. 51





Fig. 52

As it is the Company's policy to improve its products whenever opportunity occurs, designs are liable to modification at any time. In some cases, due to the nature of the part, it will be necessary for us to supply additional related parts, particularly if the item required has been altered.

SECTION GR
BED, LEADSCREW & GEAR TRAIN ASSEMBLY



GR


Part No.	Description	Qty	Part No.	Description	Qty	Part No.	Description	Qty
GR1	Bed	1	GR2	Thrust Screw	1	GR28	Simmonds Nut (7/16" B.S.F.)	1
A8724/1	Bed	1	GR3	Rack	1	GR29	Change Gear Guard Backplate	1
A2137	Rack	1	GR4	Cap Screw	1	A1960/1	Change Gear Guard Backplate	1
73/112/1	Cap Screw (2 B.A. x 1/2")	1	GR5	Change Gear Guard	1	A2023	Pad	1
73/1134/1	L.H. LeadscREW Bracket Assembly	1	GR6	Oil Nipple (2 B.A.)	1	A2022	Tension Spring	1
GR7	Stud	2	GR7	Oil Nipple (2 B.A.)	2	A2021	Round Head Screw (2 B.A. x 3/8")	3
A4725	Stud	2	GR8	Cap Screw (7/8" B.S.F. x 3/8")	4			
GR9	Change Gear Quadrant Assembly	1	GR9	Cap Screw (7/8" B.S.F. x 3/8")	4			
A4736	Change Gear Quadrant Assembly	1	GR10	Washer (7/8")	2			
GR11	Hexagon Nut (7/8" B.S.F.)	2	GR11	Hexagon Nut (7/8" B.S.F.)	2			
A1496	Change Gear Stud	2	GR12	Change Gear Stud	2			
A1501	Sleeve	2	GR13	Change Gear	2			
A1500	Bush	2	GR14	Change Gear	2			
A1499	Spacer	2	GR15	Change Gear	2			
A2054/2	Washer	2	GR16	Change Gear	2			
A2054/2	LeadscREW	1	GR17	Change Gear	1			
A2604	Spacer	1	GR18	Change Gear	1			
A1960/1	Change Gear Guard Backplate	1	GR19	Change Gear	1			
M2241	Collar	1	GR20	Change Gear	1			
M2812	Grubscrew	1	GR21	Change Gear	1			
75/1115/1	Thrust Collar	1	GR22	Change Gear	1			
75/1135/2	R.H. LeadscREW Bracket Assembly	1	GR23	Change Gear	1			
75/1114	Pin	1	GR24	Change Gear	1			
75/1113	Collar	1	GR25	Change Gear	1			
75/1114	Collar	1	GR26	Change Gear	1			
75/1113	Collar	1	GR27	Change Gear	1			
75/1114	Collar	1	GR28	Change Gear	1			
A1960/1	Change Gear Guard Backplate	1	GR29	Change Gear Guard Backplate	1			
A2023	Pad	1	GR30	Change Gear Guard Backplate	1			
A2022	Tension Spring	1	GR31	Change Gear Guard Backplate	1			
GR32	Hexagon Head Screw (7/8" B.S.F. x 1/2")	1						
GR33	Hexagon Head Screw (7/8" B.S.F. x 3/4")	1						
A1959/1	Change Gear Guard	1						
A2639	Screwcutting Chart	1						
A3018	Spring Clip	1						
GR37	Knob (Everite Ref. 221, 1/2" B.S.W.)	1						
GR38	Knob (Everite Ref. 221, 1/2" B.S.W.)	1						
A2024	Hinge Screw	1						
GR40	Hexagon Locknut (1/2" B.S.F.)	1						
GR41	Hexagon Locknut (1/2" B.S.F.)	1						
GR42	Change Gear	2						
GR43	Change Gear	2						
GR44	Change Gear	2						
GR45	Change Gear	2						
GR46	Change Gear	2						
GR47	Change Gear	2						
GR48	Change Gear	1						
GR49	Change Gear	1						
GR50	Change Gear	1						
GR51	Change Gear	1						
GR52	Change Gear	1						
GR53	Change Gear	1						

* These parts do not apply to ML7-R quick change lathes.

† For long bed lathes

GR1 Bed becomes A879/1
 GR3 Rack becomes A3470
 GR4 Cap Screws become 10 off
 GR17 LeadscREW becomes A3472/1

HEADSTOCK ASSEMBLY




SECTION H

HEADSTOCK ASSEMBLY

Part No.	Description	Qty	Part No.	Description	Qty
H1	Oil Nipple (2 B.A.)	1	H44	Washer	1
H2	Vee Cone Pulley Assembly (Includes H1)	1	H45	28T. Tumbler Gear	1
H3	60T. Backgear Assembly (Includes H4, H5, H6, H7 & H8)	1	H46	17/53T. Backgear Cluster	1
H4	Lever for Backgear Key	1	H51	Socket Set Screw (2 B.A. x 1/16") (Cup Point)	2
H5	Backgear Key	1	H52	Tumbler Reverse Lever	1
H6	Spring	1	H53	A1948/1	1
H7	Steel Ball (1/16" Dia.)	1	H54	A1949/1	1
H8	Socket Set Screw (1/8" B.S.F. x 1/16") (Cup Point)	1	H55	Backgear Lever	1
H11	A2001	1	H56	Plinger	1
H12	A1610	1	H57	Spring	1
H13	A1992	1	H58	Screwed Bush	1
H21	A1992	1	H59	Knob	1
H22	Woodruff Key No. 404	2	H60	Spring	1
H23	60° Centre (Soft)	1	H61	Socket Set Screw (1/8" B.S.F. x 1/16") (Cup Point)	1
H26	Socket Set Screw (2 B.A. x 1/16") (Cup Point)	1	H62	Spindle Bearing (Front)	1
H28	Vee Belt (Headstock) (A29-5)	1	H63	Oil Cup (90° x 3/8" B.S.P.)	1
H29	Ball Bearing (RHP 7205)	2	H64	Lubricating Wick	1
H30	A1991	1	H65	Spring	1
H31	A2055	1	H66	Socket Set Screw (1/8" B.S.F. x 1/16") (Cup Point)	1
H32	A2751	1	H67	Sealing Plug	1
H33	A2056	1	H68	Backgear Eccentric Retaining Screw	1
H34	H33	1	H69	O' Ring (B.S. 011)	1
H35	A8244	1	H70	Adjusting Ring	1
H36	A2006	1	H71	Headstock	1
H37	A1995	1	H72	Headstock	1
H38	A2005/2	1	H73	Headstock	1
H39	H38	1	H74	Headstock	1
H40	A1997/1	1	H75	Headstock	1
H42	A2023	1	H76	Headstock	1
H43	A1999	1	H77	Headstock	1
H44	A1999	1	H78	Headstock	1
H45	A1999	1	H79	Headstock	1
H46	A1999	1	H80	Headstock	1
H47	A1999	1	H81	Headstock	1
H48	A1999	1	H82	Headstock	1
H49	A1999	1	H83	Headstock	1
H50	A1999	1	H84	Headstock	1
H51	A1999	1	H85	Headstock	1
H52	A1999	1	H86	Headstock	1
H53	A1999	1	H87	Headstock	1
H54	A1999	1	H88	Headstock	1
H55	A1999	1	H89	Headstock	1
H56	A1999	1	H90	Headstock	1
H57	A1999	1	H91	Headstock	1
H58	A1999	1	H92	Headstock	1
H59	A1999	1	H93	Headstock	1
H60	A1999	1	H94	Headstock	1
H61	A1999	1	H95	Headstock	1
H62	A1999	1	H96	Headstock	1
H63	A1999	1	H97	Headstock	1
H64	A1999	1	H98	Headstock	1
H65	A1999	1	H99	Headstock	1
H66	A1999	1	H100	Headstock	1
H67	A1999	1	H101	Headstock	1
H68	A1999	1	H102	Headstock	1
H69	A1999	1	H103	Headstock	1
H70	A1999	1	H104	Headstock	1
H71	A1999	1	H105	Headstock	1
H72	A1999	1	H106	Headstock	1
H73	A1999	1	H107	Headstock	1
H74	A1999	1	H108	Headstock	1
H75	A1999	1	H109	Headstock	1
H76	A1999	1	H110	Headstock	1
H77	A1999	1	H111	Headstock	1
H78	A1999	1	H112	Headstock	1
H79	A1999	1	H113	Headstock	1
H80	A1999	1	H114	Headstock	1
H81	A1999	1	H115	Headstock	1
H82	A1999	1	H116	Headstock	1
H83	A1999	1	H117	Headstock	1
H84	A1999	1	H118	Headstock	1
H85	A1999	1	H119	Headstock	1
H86	A1999	1	H120	Headstock	1
H87	A1999	1	H121	Headstock	1
H88	A1999	1	H122	Headstock	1
H89	A1999	1	H123	Headstock	1
H90	A1999	1	H124	Headstock	1
H91	A1999	1	H125	Headstock	1
H92	A1999	1	H126	Headstock	1
H93	A1999	1	H127	Headstock	1
H94	A1999	1	H128	Headstock	1
H95	A1999	1	H129	Headstock	1
H96	A1999	1	H130	Headstock	1
H97	A1999	1	H131	Headstock	1
H98	A1999	1	H132	Headstock	1
H99	A1999	1	H133	Headstock	1
H100	A1999	1	H134	Headstock	1
H101	A1999	1	H135	Headstock	1
H102	A1999	1	H136	Headstock	1
H103	A1999	1	H137	Headstock	1
H104	A1999	1	H138	Headstock	1
H105	A1999	1	H139	Headstock	1
H106	A1999	1	H140	Headstock	1
H107	A1999	1	H141	Headstock	1
H108	A1999	1	H142	Headstock	1
H109	A1999	1	H143	Headstock	1
H110	A1999	1	H144	Headstock	1
H111	A1999	1	H145	Headstock	1
H112	A1999	1	H146	Headstock	1
H113	A1999	1	H147	Headstock	1
H114	A1999	1	H148	Headstock	1
H115	A1999	1	H149	Headstock	1
H116	A1999	1	H150	Headstock	1
H117	A1999	1	H151	Headstock	1
H118	A1999	1	H152	Headstock	1
H119	A1999	1	H153	Headstock	1
H120	A1999	1	H154	Headstock	1
H121	A1999	1	H155	Headstock	1
H122	A1999	1	H156	Headstock	1
H123	A1999	1	H157	Headstock	1
H124	A1999	1	H158	Headstock	1
H125	A1999	1	H159	Headstock	1
H126	A1999	1	H160	Headstock	1
H127	A1999	1	H161	Headstock	1
H128	A1999	1	H162	Headstock	1
H129	A1999	1	H163	Headstock	1
H130	A1999	1	H164	Headstock	1
H131	A1999	1	H165	Headstock	1
H132	A1999	1	H166	Headstock	1
H133	A1999	1	H167	Headstock	1
H134	A1999	1	H168	Headstock	1
H135	A1999	1	H169	Headstock	1
H136	A1999	1	H170	Headstock	1
H137	A1999	1	H171	Headstock	1
H138	A1999	1	H172	Headstock	1
H139	A1999	1	H173	Headstock	1
H140	A1999	1	H174	Headstock	1
H141	A1999	1	H175	Headstock	1
H142	A1999	1	H176	Headstock	1
H143	A1999	1	H177	Headstock	1
H144	A1999	1	H178	Headstock	1
H145	A1999	1	H179	Headstock	1
H146	A1999	1	H180	Headstock	1
H147	A1999	1	H181	Headstock	1
H148	A1999	1	H182	Headstock	1
H149	A1999	1	H183	Headstock	1
H150	A1999	1	H184	Headstock	1
H151	A1999	1	H185	Headstock	1
H152	A1999	1	H186	Headstock	1
H153	A1999	1	H187	Headstock	1
H154	A1999	1	H188	Headstock	1
H155	A1999	1	H189	Headstock	1
H156	A1999	1	H190	Headstock	1
H157	A1999	1	H191	Headstock	1
H158	A1999	1	H192	Headstock	1
H159	A1999	1	H193	Headstock	1
H160	A1999	1	H194	Headstock	1
H161	A1999	1	H195	Headstock	1
H162	A1999	1	H196	Headstock	1
H163	A1999	1	H197	Headstock	1
H164	A1999	1	H198	Headstock	1
H165	A1999	1	H199	Headstock	1
H166	A1999	1	H200	Headstock	1
H167	A1999	1	H201	Headstock	1
H168	A1999	1	H202	Headstock	1
H169	A1999	1	H203	Headstock	1
H170	A1999	1	H204	Headstock	1
H171	A1999	1	H205	Headstock	1
H172	A1999	1	H206	Headstock	1
H173	A1999	1	H207	Headstock	1
H174	A1999	1	H208	Headstock	1
H175	A1999	1	H209	Headstock	1
H176	A1999	1	H210	Headstock	1
H177	A1999	1	H211	Headstock	1
H178	A1999	1	H212	Headstock	1
H179	A1999	1	H213	Headstock	1
H180	A1999	1	H214	Headstock	1
H181	A1999	1	H215	Headstock	1
H182	A1999	1	H216	Headstock	1
H183	A1999	1	H217	Headstock	1
H184	A1999	1	H218	Headstock	1
H185	A1999	1	H219	Headstock	1
H186	A1999	1	H220	Headstock	1
H187	A1999	1	H221	Headstock	1
H188	A1999	1	H222	Headstock	1
H189	A1999	1	H223	Headstock	1
H190	A1999	1	H224	Headstock	1
H191	A1999	1	H225	Headstock	1
H192	A1999	1	H226	Headstock	1
H193	A1999	1	H227	Headstock	1
H194	A1999	1	H228	Headstock	1
H195	A1999	1	H229	Headstock	1
H196	A1999	1	H230	Headstock	1
H197	A1999	1	H231	Headstock	1
H198	A1999	1	H232	Headstock	1
H199	A1999	1	H233	Headstock	1
H200	A1999	1	H234	Headstock	1
H201	A1999	1	H235	Headstock	1
H202	A1999	1	H236	Headstock	1
H203	A1999	1	H237	Headstock	1
H204	A1999	1	H238	Headstock	1
H205	A1999	1	H239	Headstock	1
H206	A1999	1	H240	Headstock	1
H207	A1999	1	H241	Headstock	1
H208	A1999	1	H242	Headstock	1
H209	A1999	1	H243	Headstock	1
H210	A1999	1	H244	Headstock	1
H211	A1999	1	H245	Headstock	1
H212	A1999	1	H246	Headstock	1
H213	A1999	1	H247	Headstock	1
H214	A1999	1	H248	Headstock	1
H215	A1999	1	H249	Headstock	1
H216	A1999	1	H250	Headstock	1
H217	A1999	1	H251	Headstock	1
H218	A1999	1	H252	Headstock	1
H219	A1999	1	H253	Headstock	1
H220	A1999	1	H254	Headstock	1
H221	A1999	1	H255	Headstock	1
H222	A1999	1	H256	Headstock	1
H223	A1999	1	H257	Headstock	1

SECTION C CARRIAGE ASSEMBLY



For machines having metric feed screws with 80 and 40 division dials the following are used:—


Part No.	Description	Part No.	Description	Part No.	Description	Part No.	Description
C1	75/1412 Hexagon Nut	C31	A7742 Hexagon Head Bolt	C72	A8734/1 Saddle	C29	A8079 Top Slide Base Assy.
C2	75/1410 Spherical Washer	C33	75/1312 Clamp Eccentric	C71	A8734/1 Socket Setscrew	C27	75/1337 Cross Slide Ball Handle Assembly
C3	74/1409/1 Tool Clamp	C34	Washer (1/8")	C70	A8623 Socket Setscrew (Wedglok)	C26	73/1301 End Plate
C4	75/1413 Adjusting Screw Assembly	C35	Hexagon Head Bolt Set Screw (1/8" B.S.F. x 1 1/2") (Hard)	C69	73/1308/1 Saddle Strip (Rear)	C25	74/1321 Cross Slide Feedscrow (Metric A4730)
C5	A2806 Spring	C36	Hexagon Head Bolt Set Screw (1/8" B.S.F. x 1 1/2") (Hard)	C68	A2122 Saddle Strip (Front)	C24	A2093 Top Slide Ball Handle Assembly
C6	75/1406 Tool Clamp Stud	C37	Oil Nipple (2 B.A.)	C67	C66 Cap Screw (1/4" B.S.F. x 7/8")	C23	A3250/1 Cross Slide Micrometer Dial
C7	M12811 Grubscrew	C38	75/1304 Laminated Shim (Rear)	C66	C65 Saddle Strip (Front)	C22	M14103 Fibre Washer
C8	75/1411 Pin	C39	74/1319/1 Saddle Gib Strip	C65	A2065 Adjusting Strip	C21	75/1984A Washer (Hard)
C9	73/1403 Top Slide	C40	C41 Round Head Screw (4 B.A. x 3/8")	C64	A7424/1 Adjusting Screw	C20	Hexagon Locknut (2 B.A.)
C10	74/1408 Top Slide Feedscrow (Metric A4731)	C41	C40 Round Head Screw (4 B.A. x 3/8")	C63	A7760 Adjusting Screw	C19	M12802 Gib Adjusting Screw
C11	74/1401 End Plate	C42	Oil Nipple (2 B.A.)	C62	A8735 Wiper	C18	C17 Cheese Head Screw (4 B.A. x 3/8")
C12	Cap Screw (2 B.A. x 5/8")	C43	Hexagon Locknut (1/4" B.S.F.)	C61	A8735 Wiper	C17	75/1302 Feed Nut
C13	74/1303 Micrometer Dial	C44	75/1305 Laminated Shim (Front)	C60	A8736 Wiper Housing	C16	A1845 Tee Nut
C14	V1080 Top Slide Ball Handle Assembly	C45	75/1305 Laminated Shim (Front)	C55	M12803 Gib Strip Adjusting Screw	C15	A1845 Tee Nut
C15	A1845 Tee Nut	C46	Hexagon Locknut (1/4" B.S.F.)	C54	75/1405/2 Top Slide Gib Strip	C14	V1080 Top Slide Ball Handle Assembly
C16	75/1302 Feed Nut	C47	Hexagon Locknut (1/4" B.S.F.)	C53	74/1320/3 Cross Slide Gib Strip	C14	V1080 Top Slide Ball Handle Assembly
C17	75/1302 Feed Nut	C48	74/1319/1 Saddle Gib Strip	C52	74/1320/3 Cross Slide Gib Strip	C13	74/1303 Micrometer Dial
C18	C17 Cheese Head Screw (4 B.A. x 3/8")	C49	74/1319/1 Saddle Gib Strip	C51	75/1405/2 Top Slide Gib Strip	C12	Cap Screw (2 B.A. x 5/8")
C19	M12802 Gib Adjusting Screw	C50	A8736 Wiper Housing	C50	A8736 Wiper Housing	C11	74/1401 End Plate
C20	Hexagon Locknut (2 B.A.)	C51	M12803 Gib Strip Adjusting Screw	C51	M12803 Gib Strip Adjusting Screw	C10	74/1408 Top Slide Feedscrow (Metric A4731)
C21	75/1984A Washer (Hard)	C52	74/1320/3 Cross Slide Gib Strip	C52	74/1320/3 Cross Slide Gib Strip	C9	73/1403 Top Slide
C22	M14103 Fibre Washer	C53	A7760 Adjusting Screw	C53	A7760 Adjusting Screw	C8	75/1411 Pin
C23	A3250/1 Cross Slide Micrometer Dial	C54	75/1405/2 Top Slide Gib Strip	C54	75/1405/2 Top Slide Gib Strip	C7	M12811 Grubscrew
C24	A2093 Top Slide Ball Handle Assembly	C55	M12803 Gib Strip Adjusting Screw	C55	M12803 Gib Strip Adjusting Screw	C6	75/1406 Tool Clamp Stud
C25	A2636 Cross Slide Feedscrow Assembly	C56	Hexagon Head Bolt Set Screw (1/8" B.S.F. x 1 1/2") (Hard)	C56	Hexagon Head Bolt Set Screw (1/8" B.S.F. x 1 1/2") (Hard)	C5	A2806 Spring
C26	73/1301 End Plate	C57	Oil Nipple (2 B.A.)	C57	Oil Nipple (2 B.A.)	C4	75/1413 Adjusting Screw Assembly
C27	75/1337 Cross Slide Ball Handle Assembly	C58	C58 Laminated Shim (Rear)	C58	75/1304 Laminated Shim (Rear)	C3	74/1409/1 Tool Clamp
C28	A1648 Feed Nut (Top and Cross Slides)	C59	73/1308/1 Saddle Strip (Rear)	C59	73/1308/1 Saddle Strip (Rear)	C2	75/1410 Spherical Washer
C29	A8079 Top Slide Base Assy.	C60	A8736 Wiper Housing	C60	A8736 Wiper Housing	C1	75/1412 Hexagon Nut
C30	Washer (1/8")	C61	A8735 Wiper	C61	A8735 Wiper		
C31	75/1412 Hexagon Nut	C62	A8735 Wiper	C62	A8735 Wiper		
C32	75/1410 Spherical Washer	C63	A7760 Adjusting Screw	C63	A7760 Adjusting Screw		
C33	75/1410 Spherical Washer	C64	A7424/1 Adjusting Strip	C64	A7424/1 Adjusting Strip		
C34	Washer (1/8")	C65	A2065 Adjusting Strip	C65	A2065 Adjusting Strip		
C35	Hexagon Head Bolt Set Screw (1/8" B.S.F. x 1 1/2") (Hard)	C66	C65 Saddle Strip (Front)	C66	C65 Saddle Strip (Front)		
C36	Hexagon Head Bolt Set Screw (1/8" B.S.F. x 1 1/2") (Hard)	C67	C66 Cap Screw (1/4" B.S.F. x 7/8")	C67	C66 Cap Screw (1/4" B.S.F. x 7/8")		
C37	Oil Nipple (2 B.A.)	C68	A2122 Saddle Strip (Front)	C68	A2122 Saddle Strip (Front)		
C38	75/1304 Laminated Shim (Rear)	C69	73/1308/1 Saddle Strip (Rear)	C69	73/1308/1 Saddle Strip (Rear)		
C39	74/1319/1 Saddle Gib Strip	C70	A8623 Socket Setscrew (Wedglok)	C70	A8623 Socket Setscrew (Wedglok)		
C40	C41 Round Head Screw (4 B.A. x 3/8")	C71	A8734/1 Socket Setscrew	C71	A8734/1 Socket Setscrew		
C41	C40 Round Head Screw (4 B.A. x 3/8")	C72	A8734/1 Saddle	C72	A8734/1 Saddle		
C42	Oil Nipple (2 B.A.)						
C43	Hexagon Locknut (1/4" B.S.F.)						
C44	75/1305 Laminated Shim (Front)						
C45	75/1305 Laminated Shim (Front)						
C46	Hexagon Locknut (1/4" B.S.F.)						
C47	Hexagon Locknut (1/4" B.S.F.)						
C48	74/1319/1 Saddle Gib Strip						
C49	74/1319/1 Saddle Gib Strip						
C50	A8736 Wiper Housing						
C51	M12803 Gib Strip Adjusting Screw						
C52	74/1320/3 Cross Slide Gib Strip						
C53	A7760 Adjusting Screw						
C54	75/1405/2 Top Slide Gib Strip						
C55	M12803 Gib Strip Adjusting Screw						
C56	Hexagon Head Bolt Set Screw (1/8" B.S.F. x 1 1/2") (Hard)						
C57	Oil Nipple (2 B.A.)						
C58	C58 Laminated Shim (Rear)						
C59	73/1308/1 Saddle Strip (Rear)						
C60	A8736 Wiper Housing						
C61	A8735 Wiper						
C62	A8735 Wiper						
C63	A7760 Adjusting Screw						
C64	A7424/1 Adjusting Strip						
C65	A2065 Adjusting Strip						
C66	C65 Saddle Strip (Front)						
C67	C66 Cap Screw (1/4" B.S.F. x 7/8")						
C68	A2122 Saddle Strip (Front)						
C69	73/1308/1 Saddle Strip (Rear)						
C70	A8623 Socket Setscrew (Wedglok)						
C71	A8734/1 Socket Setscrew						
C72	A8734/1 Saddle						

MYFORD ML7-R 3 1/2" CENTRE LATHE




Drg. Part	Ref. No.	Description	No.
MR1	A209/1	Base	1
MR2	A2136	Gib Strip	1
MR3	A2137	Cap Screw (2 B.A. x 8/8")	2
MR4	A2098/1	Thrust Screw	2
MR5	A2098/1	Body	1
MR6	A2138	Oil Nipple (Tecalomit NC6055)	3
MR7	A2138	Eccentric and Lever Assembly	1
MR8	A2139	Eccentric Locating Screw	1
MR9	A2140	Eye Bolt	1
MR10	75/1514	Clamp Plate	1
MR11	MR11	Simmonds Nut (3/8" B.S.F. Type P)	2
MR12	A2146/1	Set Over Screw	2
MR13	10359	Barrel Feed Screw	1
MR14	MR14	'Oillite' Thrust Washer	1
MR15	A2114	Cap	1
MR16	A2114	Woodruff Key (No. 404)	1
MR17	A2141	Handwheel Assembly	1
MR18	A2144	Washer (1/2")	1
MR19	A2144	Barrel Key	1
MR20	A2118/1	Pad Bolt and Bush	1
MR21	10299	Stud	1
MR22	10297	Locking Lever	1
MR23	75/1248	60° Centre (Hard)	1
MR24	A2115	Barrel Assembly (Includes MR25) (Metric A8242)	1
MR25	A2117	Nut	1
MR26	MR26	Socket Set Screw (2 B.A. x 1/8") (Cup Point)	2

SECTION MR
TAILSTOCK ASSEMBLY



Drg. Part	Ref. No.	Description	No.
L1	A2086	Hand Traverse Pinion	1
L2	Woodruff Key No. 404		1
L3	M4106	Fibre Washer	2
L6	A2087	Handwheel Assembly	1
L7		Socket Set Screw (1 1/8" B.S.F. x 1/4") (Cup Point)	1
L8		'Oillite' Bush (CT 15 x 1/4")	1
L9		Cap Screw (1 1/8" B.S.F. x 3/8")	1
L10	75/1340	Gear Cover Assembly (Includes L8)	1
L11	A2085	Rack Pinion Assembly	1
L13	A4729	Spring	1
L14		Cap Screw (2 B.A. x 1 1/8")	1
L16	A9337	Hexagon Locknut (2 B.A.)	2
L17	A9337	Gib Adjusting Screw	1
L20	A2082	Gib Strip	1
L21	A2147	Gib Securing Screw	2
L22	V123	Stud	1
L23	A1837/1	Cam Lever	1
L24		Spring Washer	1
L25		Washer (1/2")	1
L26		Simmonds' Nut (1 1/8" B.S.F.)	1
L28		Hexagon Head Set Screw (2 B.A. x 1/2")	1
L29	A9338	Gib Adjusting Screw	1
L30	A4188/1	Lead Screw Guard	1
L31	A2081/2	Apron	1
L32		Cap Screw (M6 x 1 x 25 mm)	4
L33	A1975/3	Lead Screw Nut	1
L34	10508	Cam Peg	2


SECTION L
APRON ASSEMBLY



SECTION QR


MOTORISING ASSEMBLY (STANDARD)

Part No.	Description	Off/Mc.
QR1	Countershaft Arm	1
QR2	Hexagon Head Screw (1/2" B.S.F. x 7/8")	4
QR3	Stud	1
QR4	Washer (7/16")	2
QR5	Hexagon Locknut (1 1/2" B.S.F.)	2
QR6	Tension Spring	3
QR7	Round Head Screw (2 B.A. x 1 1/2")	9
QR8	Motor Base	1
QR9	Pivot Pin	1
QR10	Socket Set Screw (2 B.A. x 1/4") (Cup Point)	1
QR11	Socket Set Screw (1/2" B.S.F. x 1 1/2") (Half Dog Point)	1
A2046	Link (Point)	3
A2050	Clamp Screw	1
A2051	Clamp Screw Head	1
A2022	Washer	3
QR16	Hexagon Nut (1 1/2" B.S.F.)	3
QR17	Eccentric Shaft and Lever Assembly	1
QR18	Knob (1 1/2" Dia. x 1 1/2" B.S.W.)	1
QR19	Socket Set Screw (1/2" B.S.F. x 3/4") (Half Dog Point)	1
QR20	Swing Head Assembly (Includes QR22, QR23 and QR24)	1
A2038/1	Hexagon Nut (1 1/2" B.S.F.)	1
QR21	Oil Cup (Adams Style L No. 2511)	2
QR22	'Oilite' Bush	1
A2014	Pivot Pin	1
QR29	Adjustment Screw	1
QR28	Plug (Heyco P-625)	1
QR27	Plug (Heyco P-375)	1
QR26	End Cap	1
A3366/1	End Cap	1
QR25	Spring Clip	2
QR24	Handle (Everite Ref. 243/3, 1/4" B.S.W., x 3/8")	1
QR23	Round Head Screw (1 1/2" B.S.W., x 3/8")	1
QR22	Pivot Screw	1
QR21	Motor Pulley (3/8" Bore)	1
QR20	Motor Pulley (1/2" Bore)	1
QR19	Motor Pulley (5/8" Bore)	1
QR18	Motor Pulley (3/4" Bore)	1
QR17	Motor Pulley (7/8" Bore)	1
QR16	Motor Pulley (1" Bore)	1
QR15	Motor Pulley (1 1/8" Bore)	1
QR14	Motor Pulley (1 1/4" Bore)	1
QR13	Motor Pulley (1 1/2" Bore)	1
QR12	Motor Pulley (1 3/4" Bore)	1
QR11	Motor Pulley (1 7/8" Bore)	1
QR10	Motor Pulley (2" Bore)	1
QR9	Motor Pulley (2 1/8" Bore)	1
QR8	Motor Pulley (2 1/4" Bore)	1
QR7	Motor Pulley (2 3/8" Bore)	1
QR6	Motor Pulley (2 1/2" Bore)	1
QR5	Motor Pulley (2 7/8" Bore)	1
QR4	Motor Pulley (3" Bore)	1
QR3	Motor Pulley (3 1/8" Bore)	1
QR2	Motor Pulley (3 1/4" Bore)	1
QR1	Motor Pulley (3 1/2" Bore)	1



MOTORISING ASSEMBLY (STANDARD)

SECTION Q
MOTORISING ASSEMBLY (WITH CLUTCH)



Part No.	Description	QTY	Part No.	Description	QTY
Q64	Stud	-	Q105	Cap Screw (2 B.A. x 3/8")	-
Q63	Hexagon Locknut (1 1/2" B.S.F. x 7/8")	-	Q104	Driver Plate	-
Q62	Hexagon Locknut (1 1/2" B.S.F.)	-	Q103	Woodruff Key (No. 404)	-
Q61	Washer (1 1/2")	-	Q102	Countershaft	-
Q60	Countershaft Arm	-	A3319/1	Cir-Clip (Anderson 1400-8)	-
A1933/1	Pivot Pin (Motor Platform)	-	Q101	Collar	-
A2045	Socket Set Screw (1/2" B.S.F. x 3/4") (Half Dog Point)	-	A3330	Thrust Bearing (R. & M. FT 7/8")	-
Q58	Adjusting Screw	-	A3329	Abutment Washer	-
Q57	Round Head Screw (2 B.A. x 1 1/2")	-	Q98	Socket Countersunk Screw (2 B.A. x 1 1/4")	-
Q56	Tension Spring	-	Q97	Washer	-
A2012	Socket Set Screw (2 B.A. x 3/4") (Cup Point)	-	A3326	Diaphragm Washer	-
Q54	Motor Platform	-	A2058	Cam Shaft Assembly (Clutch Operating)	-
Q53	Clamp Screw Head	-	Q94	Motor Drive Belt Guard	-
A1945	Cam Shaft and Lever Assembly	-	A2962	Headstock Belt Guard	-
Q52	Tie Bar	-	A1935/4	Round Head Screw (2 B.A. x 1 1/2")	-
A2038/1	Socket Set Screw (1/2" B.S.F. x 3/4") (Cup Point)	-	Q90	Spring	-
Q50	Washer (1 1/2")	-	Q89	Roller and Plunger Assembly	-
Q49	Washer	-	A2939	Motor Drive Belt Guard Backplate	-
A2022	Clamp Screw	-	A4733	Spring Clip	-
Q41	Knob (1 1/2" Dia. x 1 1/8" Whitworth)	-	A2961	Motor Drive Belt Guard Backplate	-
A2050	Swing Head Pivot Shaft	-	Q87	Spring Clip	-
Q40	Hexagon Nut (1/2" B.S.F.)	-	Q85	Knob (F. W. Evans, Ref. 780)	-
Q39	Hexagon Nut (1/2" B.S.F.)	-	Q84	Round Head Screw (1 1/2" Whit. x 3/8")	-
A2014	Hinge Bracket	-	Q83	Handle	-
Q37	Washer (1 1/2")	-	Q78	Hinge Screw	-
Q36	Hexagon Head Set Screw (1 1/2" B.S.F. x 1")	-	A2043	Vee Belt (Motor Drive) (M33-5)	-
Q24	Hexagon Head Set Screw (1 1/2" B.S.F. x 1")	-	Q76	Hexagon Head Set Screw (1 1/2" B.S.F. x 3/4")	-
Q22	Socket Set Screw (1/2" B.S.F. x 3/8") (Cup Point)	-	Q75	Rivets (No. O x 1/4")	-
Q21	Socket Set Screw (1/2" B.S.F. x 3/8") (Cup Point)	-	Q71	Cap Screw (1 1/2" B.S.F. x 1 1/4")	-
Q19	Socket Set Screw (1/2" B.S.F. x 3/8") (Cup Point)	-	Q70	Motor Pulley (5/8" Bore)	-
Q13	Socket Set Screw (1/2" B.S.F. x 1/2")	-	Q67	Pad	-
Q7	Oil Cup	-	A2028/1	Spring Clip	-
Q2	Hexagon Locknut (1 1/2" B.S.F.)	-	A2044	Spring Clip	-
Q1	Hexagon Locknut (1 1/2" B.S.F.)	-	A2033	Pad	-

Continued

MYFORD ML7-R 3 $\frac{1}{2}$ " CENTRE LATHE

SECTION Q—Continued
 MOTORISING ASSEMBLY (WITH CLUTCH)

Drg. No.	Part No.	Description	No. Off/Mc.
Q106	A3312/1	Cone Pulley	1
Q107	A3313/1	Clutch Plate	1
Q108			1
Q109		Cir-Clip (Anderton 1400— $\frac{1}{8}$ ")	1
Q110		Cir-Clip (Anderton 1300— $\frac{1}{16}$ ")	1
Q111	A3359	Ball Bearing (F.B.C. SN2062)	2
Q112	A3311	Spring	1
Q113	A3328	Twin Vee Pulley	1
Q114	A3327	Spacer (Outer)	1
Q115	A3321	Spacer (Inner)	1
Q116	A3322	Push Rod	1
Q117	A3366/1	Steel Ball ($\frac{1}{2}$ " Dia.)	1
Q119		End Cap	1
Q120			1
Q121			1
Q122	A2003	Socket Set Screw ($\frac{1}{4}$ " B.S.F. x $\frac{1}{16}$ ") (Half Dog)	1
Q123		Spring	1
Q124	A5487/1	Steel Ball ($\frac{1}{16}$ " Dia.)	1
Q125	A9663	Swing Head Ass'y (includes Q7, Q29, Q57, Q125 and Q126)	1
Q126	A9664	'Oillite' Bush	1
Q127	10399	'Oillite' Bush	1
Q128		Speed Plate	1

* Standard Bore Size—other bores available—state exact size when ordering.
 † Reference Q127, part No. 10399 is the name and speed plate for ML7-R—
 not Super 7 as drawn.